

2020 Mustang Shelby GT500 Gurney Flap Installation Instructions  
**Anderson Composites Part # AC-GF20FDMU500**

Installation of flap is for track use only (per Ford Motor Company)

Instructions for installing carbon fiber  
Gurney Flap on OE spoiler.

**Installing the Gurney Flap on Anderson  
Composites spoiler are in BOLD.**

1. Remove the T20 short screws from the  
OEM decklid/spoiler assembly.

**1. Remove screws from the carbon fiber spoiler**

2. Attach the Gurney flap to the OEM spoiler assembly  
using the longer T20 screws in the four hole locations.  
Start with one screw in the center pedestal.

**2. Attach the Gurney Flap to the carbon fiber spoiler  
using the screws included with the carbon fiber  
spoiler in the four hole locations. Start with one  
screw in the center pedestal.**

3. Install the (3) remaining T20 long screws. Do not  
overtighten the screws.

**3. Install the (3) remaining screws included with  
the carbon fiber spoiler. Do not overtighten  
the screws.**

